

FIRE AND SMOKE BARRIER

SCHIEBETOR „ORPHEUS“

Optional Wicket



JANSEN TORE GMBH & CO. KG

Am Wattberg 51 | 26903 Surwold | Germany

TEL: +49 4965 8988 0 | FAX: +49 4965 8988 88 |

EMAIL: INFO@JANSENTORE.COM | WEB: WWW.JANSENTORE.COM

1 Contents

2	Fitting instructions	3
2.1	Fitting symbols and abbreviations	3
2.2	Instructions before fitting starts	3
2.3	Variants	4
2.4	Fitting the door leaf with wicket	4
2.4.1	<i>Door leaf, fitting the wicket</i>	4
2.4.2	<i>Floor termination</i>	9
2.4.3	<i>Runner</i>	10
2.4.4	<i>Cleats (EI₂90 closures only)</i>	11
2.5	Sealing (S ₂₀₀ only).....	11

2 Fitting instructions

2.1 Fitting symbols and abbreviations

The following symbols and abbreviations are used in the fitting instructions:



Symbol / Abbreviation	Meaning
	Components marked with the symbol must be aligned/fitted horizontally
	Align/fit vertically
FF	Finished floor level
CH	Clear height
CW	Clear width

2.2 Instructions before fitting starts

Before actual fitting of the door can start, we recommend that you carry out the following steps in order to ensure that everything goes smoothly:




1. Read through the full installation instructions
2. Identify door's stop side
3. Check the ordered dimensions of the door against the structural reality.
4. It is recommended that you carry out fitting in the precise order set out below or discrepancies may occur. The manufacturer is not liable for any installation errors.







2.3 Variants




Wicket without threshold	Wicket with threshold
	




2.4 Fitting the door leaf with wicket




2.4.1 Door leaf, fitting the wicket

	<ol style="list-style-type: none"> 1. Insert door elements in guide rail at top one after the other. Start with the highest number (door handle) 2. First of all, only hook in fixed section(s) and panel next to wicket hinges
	<ol style="list-style-type: none"> 3. The three/two elements are connected to each other using a push-fit system 4. The three/two elements are hooked into the next element one after the other from the top
	<p>Detach frame from wicket leaf:</p> <ol style="list-style-type: none"> 5. Detach runner from door closer 6. Undo the three middle screws for the hinge cups and remove wicket from frame






	<p>7. Put frame in, see working drawing for position of hinge side and lock side</p>	
<p>For version without smoke protection/S_a version:</p>	<p>For S₂₀₀ version:</p>	<p>8. Adjust frame height as shown in illustration</p>
<p>With threshold:</p>		
		
<p>Without threshold:</p>		
		
	<p>9. Only set the top two $\varnothing 4$ blind rivets on both sides of hinge side</p>	



	<p>10. Connect element next to wicket using push-fit system</p>
	<p>Wickets without threshold only:</p> <ol style="list-style-type: none"> 11. Insert threaded rod 12. Align elements 13. Secure and lock both sides with two nuts 14. Cut threaded rod off immediately after nut
	<ol style="list-style-type: none"> 15. Connect all remaining elements, if any, for labyrinth side/lead-in side using push-fit system 16. Connect all remaining elements, if any, for labyrinth side/lead-in side using push-fit system 17. Align door leaf vertically 

	<ol style="list-style-type: none"> 18. Align frame on hinge side and include 5 mm of prestressing 19. Fix frame in place on both sides on hinge side (countersunk self-tapping screw $\varnothing 4.8 \times 50$) 										
	<p>Hang wicket:</p> <ol style="list-style-type: none"> 20. Insert hinges in frame's hinge pockets 21. Tighten the three middle screws 22. The two outer screws can be used for fine adjustment 23. Hook runner in 										
<p>Overhead door closer:</p>											
 <p>a (mm) - EN</p> <table border="1"> <tr><td>1400</td><td>6</td></tr> <tr><td>1250</td><td>5</td></tr> <tr><td>1100</td><td>4</td></tr> <tr><td>950</td><td>3</td></tr> <tr><td>850</td><td>2</td></tr> </table>	1400	6	1250	5	1100	4	950	3	850	2	<ol style="list-style-type: none"> 24. Press cover lightly and push to side 25. Adjust door closer manually using setscrew. See diagram for precise setting
1400	6										
1250	5										
1100	4										
950	3										
850	2										


Internal door closer:	
	<p>26. Open wicket 27. Adjust manually using door closer's setscrews (see illustrations)</p>
	<p>28. Align frame with wicket 29. Make sure that the round-head screws in the case of S_a and the locks in the wicket in the case of S₂₀₀ are centred in relation to the cutouts in the frame</p>
	<p>30. Fix frame in place at top from both sides (blind rivet $\varnothing 4$) 31. Fix frame in place from both sides on lock side (countersunk self-tapping screw $\varnothing 4.8 \times 50$)</p>

2.4.2 Floor termination



With threshold S_a/S_{200} , without threshold S_a		
<p>S_a version:</p> 	<p>32. Align end cover</p> <p>33. For without threshold S_a left and right next to frame only, under wicket is omitted (approx. 2 mm gap between frame and end cover)</p>	
<p>S_{200} version:</p> 	<p>34. Comply with floor gap (see next illustration)</p> <p>35. Rivet to door element (blind rivet $\varnothing 4 \times 10$)</p>	
<p>For version without smoke protection/S_a version:</p>  <p style="text-align: center;">S_{24}</p>	<p>For S_{200} version:</p>  <p style="text-align: center;">S_{21}</p>	<p>36. The end cover is different for the version without smoke protection properties/S_a version and the S_{200} version</p> <p>37. It is imperative that the floor gap dimensions are complied with!</p>
Without threshold S_{200} :		
<p>Seen from wall side:</p>  <p style="text-align: center;">Fitting </p> <p style="text-align: center;">S_{21}</p>	<p>38. Align fitting pieces and end cover (approx. 2 mm gap between frame and fitting pieces)</p> <p>39. Comply with floor gap (see illustration)</p> <p>40. Rivet to door element (blind rivet $\varnothing 4 \times 10$)</p>	

	<p>41. Move door seal so that there is only a max. 2 mm gap between the two seals</p> <p>42. To ensure that the sealing plane is not interrupted at the floor in the case of S₂₀₀ doors (without threshold), the seal receivers must be adjusted in such a way that the seals run in one plane</p>
	<p>43. Secure seal right and left next to wicket approx. 100 mm away from receiver (blind rivet ø4)</p>

2.4.3 Runner

	<p>44. Align runner flush with end cover</p> <p>45. Comply with dimensions (see illustration)</p> <p>46. Fix runner in place (2 x countersunk self-tapping screw ø3.9x25)</p>
---	--


2.4.4 Cleats (EI₂90 closures only)



		<p>47. Align cleats horizontally</p> <p>48. Comply with dimensions (see illustrations)</p> <p>49. Screw together in all holes (flat-head self-tapping screw $\varnothing 4.2 \times 13$)</p>
---	---	--

Continue fitting the door from *Fitting the wall labyrinth, floor guide...*

2.5 Sealing (S₂₀₀ only)

To comply with **S₂₀₀ requirements**, the wicket must be sealed using a non-shrink method as well. This must be done after installation of the door has been completed. A distinction is made between out of reveal and into reveal:

<p>Out of reveal:</p>	
 	<p>50. The frame must be sealed to the door leaf on three sides on the opposite hinge side</p> <p>51. The frame must be sealed to the door leaf at the bottom right and left on the opposite hinge side</p>

Into reveal:	
	<p>52. The frame must be sealed to the door leaf on three sides on the hinge side</p> <p>53. The frame must be sealed to the door leaf at the bottom right and left on the hinge side</p>
	<p>54. Open wicket</p> <p>55. Seal wicket at bottom on both sides using a non-shrink method as shown in illustration</p>
	<p>56. With an 'into reveal' wicket, the seal must be sealed on the right and left in such a way that it is in contact with the frame</p> <p>57. Open wicket and seal on both sides as shown in illustration</p>